



# Space Information Laboratories

## **Lithium Ion *Intelli-Pack* Battery**

***For Launch Vehicles, Missiles, Satellites, ISS,  
Balloons, Aircraft and UAVs***


***An Intelligent Power System Technology***

**NASA MSFC Battery Workshop  
14-18 November 2011**



# SIL Technology Video

Duration 2 Minutes





# Li-Polymer Battery Technology

## Typical Lithium Ion Polymer 4.2Vdc Cell (.5 to 50 Ah)



- 2.97" L x 2.56" W x .2" H
- 4.2V, 5 Ah, 233.5 Wh/Kg
- Solid Polymer Electrolyte with no electrolyte leakage
- Works in a space vacuum
- Teflon wire soldered directly to tabs – no risky weld joints



# SIL Cell Battery Testing


- SIL performs Li-Ion Polymer and Li-Ion 18650 cell screening testing prior to assembling the Lithium Intelli-Pack Battery System for LV/Missile, Satellite, ISS and other Aerospace platforms.
  - Cell screening performed per RCC 319-07 Lithium Ion Section 4.26 (capacity, self discharge / long-term storage, load test characterization, and temperature cycling).
  - Testing is performed in a vacuum at C/10 to C/2 discharge rates for satellite applications.
  - Cells are characterized and matched by lot and performance to ensure uniform pack / balancing characteristics



# Li-Polymer Battery Technology Features

- Lithium Polymer cells have ***no liquid or toxic electrolyte***
- Immune to vibration and shock with proper constraints
- Tested in hard space vacuum and flown on CubeSats and AFRL SmallSats without issue
- ***Mechanically adaptable*** to multiple dimensions
- ***High energy density***, 200-250 Wh/Kg
  - *3x the density of Ni-cad Batteries*
  - *6x the density of Lead-Acid Batteries*
  - *2x the density of Silver Zinc Batteries*
  - *~1.5x the density of typical Lithium-Ion cells*
- ***Wide thermal operating range*** of -20C to +70C
- ***Excellent performance under cold temperatures*** as compared to Ni-Cad, Silver Zinc and/or Lithium Ion batteries
- No maintenance or complex lab equipment required for conditioning or safety

# Relative Energy Densities





# SIL Aerospace Battery Comparison Chart

Battery Characteristic	Silver Zinc	Lithium-ion Polymer	Nickel Cadmium	Lithium-ion Iron Phosphate	Lithium Ion Cylinder
Cost ( \$ / Wh)	50 - 75	1	.75 – 1.5	1.5 - 2	1 – 1.5
Cell Voltage (V)	1.85V - 1.2V	4.2V – 3V	1.4V – 1V	3.7 V – 2.5V	3.6V – 2.2V
Current Sink Capability	3 – 4 C 5 - 10C (Pulse)	2 – 5 C 10C (Pulse)	1 – 2 C	2 C 3-4C (Pulse)	1C
Energy Density (Wh / Kg)	70 – 100 Wh/Kg	200 – 250 Wh/Kg	30 – 45 Wh/Kg	125-150 Wh/Kg	125-200 Wh/Kg
Temperature Range (C)	+4C - +74C	-20C - +70C	-20C - +50C	-20C - +70C	-20C - +50C
Mechanical Adaptability	Limited Configurations	Unlimited Configurations	Limited Configurations	Limited Configurations	Limited Configurations
Cycle Life	10 to 30 Cycles	>500 cycles to 80% rated capacity	>1000 Cycles to 80% rated capacity	>2000 Cycles to 80% rated capacity	> 500 Cycles to 80% rated capacity
Liquid Electrolyte	Yes, Subject to Leakage – Potassium Hydroxide	No	Yes, Subject to Leakage – Potassium Hydroxide	Yes, Subject to Leakage – Lithium Salt in Organic Solvent	Yes, Subject to Leakage – EC:DMC:DEC:EMC
Vibration and Shock Tolerance	Good	Excellent	Good	Good	Good
Optimal Recharge Time	16 hours @ C/2	2-3 hours @ C/2	16 hours @ C/4	4-6 hours @ C/4	12 hours @ C/3
Memory Effect	None	None	Yes	None	None




# Methodology and Design Approach

- **Modular, scalable and flexible** battery design with cell voltage monitoring, individual cell protection (under voltage, over voltage and short circuit) and balancing
- **Thermal control** of battery temperature via optional Kapton strip heaters between the cells for operating in temperatures below -20C
- **Wide variety of external telemetry interfaces** including RS-232, RS-422, USB, I2C, 1553B, Arinc 429, Spacewire, etc...
- **Custom GUI Software** for real time battery system monitoring and test evaluation (Functional Qualification / ATP Testing)
- **38999 Series III connectors** for simple integration with existing and future aerospace systems
- **Ease of Integration** into customer applications using either SIL or customer provided enclosures and mounting hardware
- **Total support** throughout design, integration, and operation from a team committed to excellence



# Scalable, Modular and Intelligent Power System (SMIPS)





## Cell Protection, Balancing and Monitoring

- Over-voltage Protection 4.15 to 4.4 +/- 0.050V
- Under-voltage Protection 2.0 to 2.9 +/- 0.10V
- Battery Discharge Protection
  - Configurable Over-Current Protection
- Cell Balancing
  - Battery management system balances cells during charging to ensure individual cells in series are at the same state of charge (SOC)
- Monitoring (RS-232, RS-422, USB, I2C, Arinc 429, 1553B Ports)
  - The battery management system monitors overall battery state of charge, individual cell voltages, battery temperature, and charge/discharge current



# 12.6Vdc CubeSat Intelli-Pack Battery System (3AH)



## SIL Intelli-Pack™ and Intelli-Cell™ Advanced Lithium Polymer Battery System

*An intelligent solution for today's aerospace applications*

### FEATURES

- Overvoltage and Undervoltage Protection
- Overdischarge / Short Circuit Protection
- Parallel Pack Redundancy
- Individual Cell voltage monitoring and recording
- Solar Charge Regulator
- Kapton Strip Heaters between cells with automatic heater activation at -10C to 0C
- Temperature monitoring on each 12.6Vdc Pack
- Each 12.6Vdc Li-Polymer Battery (three Li-Polymer Cells, 4.2Vdc, 1.6AH each)
- Regulated +5Vdc and +3.3Vdc Military rated DC-DC Converters
- RS-422 and/or I2C Interface for transfer of battery information for satellite downlink
- Upgradeable and Expandable (Modular and Scalable Design)
- Shock, Vibration, Space Qualified (Minuteman III Levels)

A 12.6V PnP Nano-Sat Intelli-Pack BATTERY CONFIGURATION





SIL Proprietary

SIL Patent Pending




# SIL 33.6Vdc Avionics Intelli-Pack Battery System (6.6AH)



Individual Cell Protection / Monitoring

A 33.6V FLIGHT BATTERY CONFIGURATION

Weight: 5 lbs  
Size: 5.5"L x 4.7"W x 3.5"H






# SIL 33.6Vdc Avionics Intelli-Pack Battery System (20 AH)


Weight: 13.5 lbs

Size: 9" L x 7.5" W x 3.5" H


RS-422 and MIL-STD 1553B Data Outputs



# Li-Polymer Intell-Pack Windows GUI




# Charging Data – 33.6V, 10Ah Pack



- Charge Time for 10Ah SIL Lithium Ion Polymer Intelli-Pack
- 130 minutes total charge time at C/2 (5A) charge current
- Charge rate can be safely increased to 1C (10A)



## Discharge Data – 33.6V, 10Ah Pack



- 1C Discharge Rate – 10A Load
- Flat Discharge Curve with ~ 57 minute run time
- Undervoltage protection cutoff at 2.7V / cell





# Environmental Qualification Levels

**Operating temp:** - 20C to +70C

**Storage temp:** - 55C to +85C

## **Qualified to DOD Missile Environment Levels**

**Thermal Humidity:** -20C to +60C (24 cycles, 1 hour dwells at each temperature extreme)

**Thermal Vacuum:** 400,000 Ft. ( $2 \times 10^{-7}$  PSIA)  
-20C to +60C

**Random Vib.:** 26.4 grms, 3-Axis, 0-2000Hz

**Sine Vibration:** 14.14 Gpk, 0-300Hz and  
21.21 Gpk, 301Hz to 2000Hz, 3 Axis

**Shock:** 40G, 11msec, 3-Axis, bi-directional, 12 Shocks

**Acceleration:** 30G, 3-Axis, bi-directional

**Outgassing:** Space Shuttle, all NASA codes

**EMIC:** MIL-STD 461D CE102, CS101, CS114, CS115,  
CS116, RE102, RE103



## Way Ahead

- SIL's Lithium Intelli-Pack™ battery is adaptable for use in any size/configuration where a highly reliable, energy dense, intelligent power source is required for Launch Vehicles, Missiles, Satellites, ISS, Balloons and UAVs
- SIL's Lithium Intelli-Pack Batteries provide voltage monitoring for use during preflight conditioning and for in flight telemetry downlink via multiple communication interfaces
- SIL's Lithium Intelli-Pack is a **cost effective, easily qualified,** and **safe** alternative to current chemistries.
- SIL desires to work with the NASA and the DOD to utilize the Lithium Intelli-Pack battery technology to **meet** and **exceed** all existing and future aerospace battery requirements.



SIL Contacts for more Info

## **Please visit the SIL Booth to see the Lithium Intelli-Pack Battery**

### **Space Information Laboratories**

Edmund Burke, President

Jason Walsh, Director of R&D

Santa Maria, California

Phone: 805-925-9010, Ext. 1#

Cell: 805-720-2784

Fax: 805-925-9017

E-mail: [edmund.burke@spaceinformationlabs.com](mailto:edmund.burke@spaceinformationlabs.com)

[www.spaceinformationlabs.com](http://www.spaceinformationlabs.com)