



## Advantages of High Molecular Weight PVDF Binder in Lithium Ion Cells

Ramin Amin-Sanayei, Ph.D.  
Principal Scientist  
Arkema Inc.  
King of Prussia, PA

Rosemary Heinze  
Market Manager  
Arkema Inc.  
Philadelphia, PA

*2009 NASA Aerospace Battery Workshop  
Huntsville, AL*

November 17–19, 2009


# Introduction

---

- Polyvinylidene fluoride (PVDF) polymers are widely used as binders in lithium ion batteries.
- Certain grades of PVDF are synthesized especially for binder use.
- The polymerization process and the molecular weight make a difference in binder processing and performance.

# Key Attributes of Battery Binder

---



# Experimental

## *materials*

---

PVDF materials used in this work			
Code	Polymerization Process	*Solution Viscosity (cp)	Remark
A	Emulsion Polymerization	501	Arkema Commercial Product
B	Emulsion Polymerization	1081	Arkema Developmental Grade
C	Suspension Polymerization	390	Commercial Product
*Solution viscosity refers to the one of 5 wt% solution in NMP, measured at 25°C using a Brookfield viscometer			

# Emulsion vs Suspension PVDF

---

- Inherent Advantages of Emulsion Grades
  - Dissolves Easier and Faster in Solvent
    - Due to Nanometer-scale Particle size Versus Micron-scale Particle Size
  - Very Mono-dispersed Particle Size Distribution
    - Provides better control during dissolution process
  - Super High Molecular Weight PVDF Can Be Synthesized

# Experimental

## *Slurry Formulations*

---



Slurry formulations of LFP cathode				
Electrode ID	PVDF Type	Weight Percent		
		PVDF	Total Solids	NMP
PE# 1	A	5.0%	49.5%	50.5%
PE# 2	B	5.0%	48%	52%
PE# 3	C	5.0%	49.5%	50.5%
The NMP concentration was adjusted to give a viscosity value compatible with a good coating.				

# Experimental

## *electrodes*

---


- Cathode specimens were evaluated for peel strength using an Instron Tensiometer
- Electrodes were used to fabricate 18650 cells using a standard anode and electrolyte



# Results

*peel strength*


## Peel Strength of LFP electrodes 5% binder loading





# Results

## *cell performance*



# Conclusion

---

- The peel strength of the cathode was profoundly affected by the MW of the PVDF
- Emulsion-polymerized grades can provide higher peel strength at the same loading as suspension-polymerized grades
- The cell capacity can be significantly improved by using PVDF homopolymer of super high molecular weight

# Appendix

---

- Contact information
- Solvents for Kynar® PVDF resins
- Solution viscosity chart

# Contact Us

---

Rosemary Heinze, Market Manager.  
[rosemary.heinze@arkema.com](mailto:rosemary.heinze@arkema.com).  
1.800.KYNAR50.

Ramin Amin-Sanayei, Principal Scientist.  
[ramin.amin-sanayei@arkema.com](mailto:ramin.amin-sanayei@arkema.com).

Global office listing at [www.kynar.com](http://www.kynar.com).

*Kynar® is a registered trademark of Arkema Inc.*



# Solvents for Kynar<sup>®</sup> resins

---

## Active Solvents

- Dimethyl Formamide (DMF)
- Dimethyl Acetamide (DMAc)
- Tetramethyl Urea
- Dimethyl Sulfoxide (DMSO)
- Triethyl Phosphate (TEP)
- N-Methyl-2-Pyrrolidone (NMP)

## Latent Solvents

- Acetone
- THF
- MEK
- MIBK
- Glycol Ethers
- n-Butyl Acetate
- Cyclohexanone
- Isophorone
- DMC, DEC, PC

# Solution Viscosity improvement of Kynar<sup>®</sup> PVDF

